




Installation Instructions




tissino




Fix the Position of the Tap.
Leave Space and Make
Holes for Anchor Bolts.




Turn on the Water Supply
and Check for Leakage.




Connect the Water Pipes.
Fasten the Anchor Bolts after
Horizontal Adjustment.
Adjust the Level after Fasten the
Bolts.




Turn off the Water Supply
and Remove the Test
Parts.




Install the Water Testing
Parts.




Install the Flushing
Parts.




Flush out /Clean the Water Pipes.



Cut-off the Remaining Visible Plastic Housing and Remove Cover.







Turn off the Water Supply and Remove the Flushing Parts.



Put Cover Plate Back on.
After Installation of Flooring/Tiles, Ensure all Gaps are Adequately Sealed.

Important Information- Complying thoroughly with the following installation, use and maintenance instructions allows the best product working and maintenance. Tissino does not warrant their product in case of damages caused by the non-compliance of these instructions.



Tissino
Unit 2a Lyncastle Rd,
Appleton Thorn,
Warrington
WA4 4SN

www.tissino.co.uk